



MAVERICK

2022+ Ford Maverick (ALL MODELS) Ditch Light Bracket Installation Guide

Professional installation recommended.

Step 1. Remove 2 nuts holding passenger's side hood hinge to hood.



Step 2. Place ditch light bracket over mounting studs, reinstall nuts.



Step 3. Using paint shadow as a reference, align hood and tighten nuts.

Step 4. Using provided M8x16 bolt and nut, install off-road light of your choice onto bracket. (Hardware provided with lights is typically too long and may contact the hood.)



Step 5. Repeat steps 1-4 for passenger side.

Step 9. Find some trails!!



**For tech support, please call 1-844- HRG LIFT (474-5438) from 8-4:30 PM EST
Mon-Thu 8-3:30 PM Fri or email us 24/7 at support@hrgoffroad.com.**

This product is intended for off-road use only!!

Copyright HRG Offroad 2026