



2002-2006 CR-V front skid plate installation guide

Professional installation is recommended

Included in the kit:

- 1 Skid plate
- 4 1"x 1/2" bolts
- 4 1/2" Rivnuts

Tools required:

Rivnut tool, 5/8" socket

Step 1. Lift vehicle and support with jack stands.

Step 2. Locate holes in front subframe that line up with the holes on the skid plate.

Step 3. Using a rivnut installation tool, install rivnuts in holes in subframe.



Step 4. Place skid plate under vehicle and secure with 4 1" long x 1/2" bolts.



Step 5. Tighten bolts with 5/8" socket. Do not overtighten bolts!

Step 6. Hit some trails!

**For tech support, please call 1-844- HRG LIFT (474-5438) from 8-4:30 PM EST
Mon-Thu 8-3:30 PM Fri or email us 24/7 at support@hrgoffroad.com.**

This product is intended for off-road use only!!

Copyright HRG Offroad. 2024